


NEW RADIO REVIEW

VRS AND DVRS AND REPEATERS, OH MY!



THE MAIN RADIO



THE MAIN RADIO

POWER →



PUSHING THE POWER ON/OFF WILL TURN ON/OFF BOTH THE FRONT AND BACK RADIOS



THE MAIN RADIO

LED LIGHTS →



FLASHING RED = RADIO FAILED
SOLID RED = YOU ARE TRANSMITTING
FLASHING YELLOW = RECEIVING A TRANSMISSION
SOLID YELLOW = CHANNEL IS BUSY
GREEN = RADIO POWERED UP PROPERLY



THE MAIN RADIO

VOLUME KNOB



THE MINIMUM VOLUME IS 20%



THE MAIN RADIO



AD = ADVANCED DEPLOYMENT = **A**NALOG

AD-LON = ANALOG LONDON CACC ZONE *CURRENT

LON = DIGITAL LONDON CACC ZONE



THE MAIN RADIO



ZONE ARE LISTED GEOGRAPHICALLY

ALL THE ANALOG ZONES (AD) ARE TOGETHER

ALL THE DIGITAL ZONES ARE TOGETHER



ZONE



THE MAIN RADIO

CHANNEL KNOB



ROTATING THE CHANNEL KNOB WILL CHANGE THE CHANNELS (TALKGROUPS) IN THE ZONE FOLDER (E.G., AD-LONCITY 1, AD-LONWEST, AD-LONTAC1, ETC.)



THE MAIN RADIO



MEMORY SELECT BUTTONS

EASILY PROGRAMMED TO FAVOURITE CHANNELS OR SET UP CHANNELS FOR TRANSFERS

FIND THE ZONE & CHANNEL YOU WANT, THEN HOLD DOWN MS BUTTON UNTIL BEEP IS HEARD



THE MAIN RADIO

BACKLIGHT BUTTON



HOLD DOWN TO SWITCH BETWEEN DAY AND NIGHT MODE

SHORT PRESSES WILL DIM SCREEN (IT CAN DIM RIGHT OFF)



THE MAIN RADIO

TO CLEAR ALARM

“LONDON, (TRUCK NO.) 10-2000 ALPHA-CHARLIE, DELTA/ECHO”



EMERGENCY BUTTON

PUSH TO ACTIVATE EMERGENCY ALARM

SCREEN WILL FLASH ORANGE

DISPATCH WILL ACKNOWLEDGE ALARM BY SAYING,
“ALL UNITS 10-3, (YOUR TRUCK NO.) 10-4”



THE MAIN RADIO



HOME BUTTON

LONG HOLD = PCOM

SHORT PRESS = BACK BUTTON



THE MAIN RADIO

REMEMBER: THE VR SHOULD BE OFF WHEN YOU ARE MOBILE!



REPEATER


P = PORTABLES, PARK, REPEATER

SHORT PUSHES TURNS VEHICLE REPEATER ON (SYS) AND OFF



THE MAIN RADIO

WHEN VEHICLE REPEATER IS ON
PORTABLES WILL WORK



REPEATER


P = PORTABLES, PARK, REPEATER

SHORT PUSHES TURNS VEHICLE REPEATER ON (SYS) AND OFF



THE MAIN RADIO

VEHICLE REPEATER CHANNEL
MLPS IS ASSIGNED VR01




REPEATER

TO CHANGE ANYTHING WITH THE REPEATER
HOLD DOWN THE "P" BUTTON



THE MAIN RADIO

SCROLL UP AND DOWN TO FIND VR CHANNEL AND PUSH "SEL" ONCE DESIRED CHANNEL IS HIGHLIGHTED



THIS SCREEN WILL TIME OUT AND ADOPT ANY SETTINGS YOU HAVE HIGHLIGHTED

REPEATER

TO PUT RADIO IN LOCAL MODE:
PUSH THE MODE BUTTON UNTIL VR LOCAL IS SEEN IN TOP LINE
(IT WILL CYCLE BETWEEN VR OFF, VR SYSTEMS AND VR LOCAL)
THEN PUSH "SEL" TO SELECT



THE MAIN RADIO

VEHICLE REPEATER IS IN LOCAL MODE



LOCAL MODE ENABLES USERS TO TALK
PORTABLE TO PORTABLE
WITHOUT OTHERS HEARING TRANSMISSIONS, BUT USERS
CAN STILL RECEIVE TRANSMISSIONS



PORTABLE RADIO




EMERGENCY
BUTTON

CHANNEL KNOB

ON/OFF
AND VOLUME
KNOB

DISABLED



REPEATER ACTIVATION
BUTTON

PUSH TO TALK

KEYPAD LOCK BUTTON



PORTABLE RADIO

EACH PORTABLE IS ASSIGNED AN ALIAS NAME, SPECIFIC TO THE TRUCK IT BELONGS TO (E.G., 1181A)

DISPATCH WILL SEE THIS NAME WHEN AN EMERGENCY BUTTON IS PRESSED



EMERGENCY
BUTTONS

ON/OFF
AND VOLUME
KNOB

MIN. VOLUME
IS 20%

QUIET/LOUD
VOLUME FOR
LAPEL MIC



PORTABLE RADIO

VR CHANNEL MUST MATCH VR CHANNEL SET ON MAIN RADIO




CHANNEL KNOB

“OOR” WILL DISPLAY ON SCREEN WHEN YOU ARE NOT CONNECTED TO A REPEATER



PORTABLE RADIO



USE THE REPEATER ACTIVATION BUTTONS TO **REMOTELY TURN THE VEHICLE REPEATER ON**
(WILL NOT TURN THE REPEATER OFF)

THIS BUTTON CAN ALSO BE USED TO TURN THE MAIN RADIO FROM LOC TO SYS



PORTABLE RADIO

HOLD DOWN THE KEYPAD LOCK TO LOCK ALL BUTTONS ON THE FRONT OF THE PORTABLE

THE BUTTONS ON TOP AND SIDE OF PORTABLE WILL STILL FUNCTION (E.G., EMERGENCY ALARM, REPEATER ACTIVATION, CHANNEL KNOB, PTT AND VOLUME)



KEYPAD LOCK BUTTON




PORTABLE RADIO



PORTABLE RADIO



ZONES



IF YOU ARE IN A DIGITAL CACC ZONE, SET PORTABLE TO DVR (DIGITAL VEHICLE REPEATER)

INT = INTEROPERABILITY


IF YOU ARE IN AN ANALOG CACC ZONE, SET PORTABLE TO VR



PORTABLE RADIO



PROFILES



DEFAULT PROFILE

SURVEILLANCE – SCREENS WILL NOT LIGHT UP, NO BEEPING SOUNDS, VOLUME CAN BE TRUE ZERO

LOUD AUDIO – FILTERS OUT BACKGROUND NOISE AT YOUR LOCATION (E.G., CONCERT)



PORTABLE RADIO



BATTERY



INDICATES BATTERY
CHARGE



PORTABLE RADIO



LOCATION



REFRESHES THE GPS COORDINATES

GPS IS FUNCTIONING IF SATELLITE IMAGE IS SOLID

GPS COORDINATES

*GPS COORDINATES ARE NOT FORWARDED TO CACC. THEY HAVE ACETECH TO IDENTIFY TRUCK LOCATIONS



PORTABLE LEVEL COVERAGE (PLC) SITES

PLACES LIKE WINDSOR TUNNEL,
TORONTO/YORK SUBWAY, WASAGA BEACH
AND SOME HOSPITALS HAVE REPEATERS

CLOSEST SITE TO US IS ST. THOMAS
ELGIN GENERAL HOSPITAL

TURN VR CHANNEL TO 7

NO NEED TO TURN ON VEHICLE
REPEATER



TALK AROUND MODE (WALKIE TALKIES)

WHEN BOTH PORTABLES ARE OUT OF RANGE
(OOR) OF A REPEATER

AND

IN RANGE OF EACH OTHER (WITHIN 2KM)

AND

ON SAME VR CHANNEL



THERE IS A DELAY BEFORE YOU CAN TALK,
WAIT FOR LOW BONK SOUND FOLLOWED
BY CHIRPS




TALK AROUND MODE CONT'D

IF ONE OF THE PORTABLES GETS IN RANGE OF A REPEATER:

THAT PORTABLE CAN HAVE TWO WAY COMMUNICATION WITH DISPATCH AND CAN HEAR THE OTHER PORTABLE THAT IS STILL OUT OF RANGE

BUT THEY CAN NOT TALK TO THE OTHER PORTABLE



FOR MORE INFORMATION

LOG ONTO THE PARAMEDIC PORTAL
OF ONTARIO AND LOOK FOR THE
OPERATING MANUAL IN THE MOH
RADIO TRAINING MODULE

Ministry of Health Courses

Ministry of Health: Public Safety Radio Network Advanced Deployment (PSRN)

100% complete

PSRN Operating Manual for Paramedics

Advanced Deployment



Emergency Health Program Management and Delivery Branch
Ministry of Health

Version: 5.1
September 2022

Ontario 

